Punitapi Chan

Buttons

The straw is also technically a button, as you can press down on it, but you can also additionally move it side to side to "stir" your beverage!

A is to select/scroll through the options

B is to confirm on the selection

C is back/cancel

Setting up the device

Before you start playing, you need to set up the device. You will first have to set the date.

Press A to scroll through the month, and then press B to confirm. Repeat with the day.

Next, set the time

Next, set your birthday.

You are now all set! You will now come to the homepage, where you'll see your beverage, and the time. We will call this your homepage.

he homepage seems really empty now, but not to worry!

You will soon fill them up with adorable Tapi-Chans!



Screen Saver

If you press C while you are on the home screen, the time will disappear and it will go into screen saver mode.

In the image example, I have already unlocked many Tapi-Chans, so my screensaver is full of them!

Menu Icons

If you press B while you are on the home screen, you will come to the menu page.

There are 7 icons in total.

3 on top and 4 on the bottom.

Hunting for a new Tapi-Chan

If you select the first icon (magnifying glass icon) on the top row, you will be able to hunt and unlock new Tapi-Chan.

Tapi-Chans that you have unlocked will appear in the collection library, and you will be also able to display them on your home page.

Remember to try all combinations of beverage color, ice level, and sugar level!

Different combinations unlocks different types of Tapi-Chan!

After selecting the magnifying glass icon, you will need to customise your beverage:

beverage color

amount of ice

sugar level

After confirming your customisation, it is time to catch Tapi-Chan!

Step 1:

Move the straw side to side to stir the beverage, as indicated by the red arrows.



Step 2:

After stirring a bit, a translucent pink heart will appear, and the red arrow points down.



Step 3:

When the Tapi-Chan you are supposed to catch moves into the area of the heart, the heart will turn a darker pink! At this moment, press down on the straw!

Step 4:

Continue pressing down on the straw to "suck" it upwards.

Step 5:

When the arrows change to point left and right, it means Tapi-Chan is stuck! Move the straw left and right to shake it loose!



Step 6:

Continue to "suck" by pressing down on the straw. Keep repeating this until t is caught!

Step 7:

In this example, we have caught the "Idol" Tapi-Chan!

Change the homepage display

If you select the second icon on the top row, you will be able to customise your home screen.



Select Tapi-Chan

Select the beverage color

Step 1:

Select which Tapi-Chan you want to display on your home screen. You can only select those that you have unlocked.

There are 6 categories of Tapi-Chans:

1, 2, 3, 4, 5, and S.

Each category has 16-17 different types of Tapi-Chans, except for category S which has 21 types.

To remove the Tapi-Chan from the home screen, select it once. Select it again to put it back into the home screen.



Tapi-Chans with a smiley icon indicate they are displayed on the home screen, and those without a smiley face mean they are removed from the home screen.



Step 2:

Select the color of the beverage you want to display on the home page.

At the beginning, you can only select yellow and pink beverage colors. As you progress, you will unlock more colors.

There are 6 in total you can pick from.



Continue Step 3:

after you are done customising, press C twice to return to the home page, and you will see that your home page is now changed according to your preferences!

Mini Games

If you select the third icon on the top row, you will be able to play mini games to earn money. The better you play the game, the more money you earn! Money earned here can be used at the market to purchase new ingredients to make new beverages!

There are 6 games in total. At the beginning, you can only access 2 games.

You will unlock more games as you progress!

Game 1

Press A and B to move your cup left and right. Catch as many Tapi-Chans as possible while avoiding the ones that have gone bad! The more Tapi-Chans you catch, the more points you earn.

Bad Tapi-Chan



Good Tapi-Chan

Game 2

There will be a moving carousel with cups and cans. Press down on the straw at the right timing to insert the straw into the cups, but avoid the cans! The more cups you put straws into, the more points you earn.





Game 3

Select the corresponding color of the cup cap and body according to the customers' orders.

Press A to scroll through the selection and B to confirm the selection.



Game 4

Copy the girl's dance moves. There are 3 moves: Left, Jump, and Right. First, watch the girl's dance moves.

Then, repeat the moves by pressing A (Left), B (Jump), or C (Right) in the correct sequence.

Repeat this 5 times to win a perfect game.

Game 5

There will be a girl on the screen who is moving along the floor tiles.
When she moves onto the tiles with rubbish or spills on it, move the straw side to side repeatedly to clean that tile.
After it is clean, stop moving the straw and she will continue to move on to the next tile.
Repeat until all the tiles on the screen is cleaned up.

Game 6

There are 4 cards on the screen.
Out of the 4, 2 of them will be a pair with the same image.

Remember the location of this pair.

The cards will then be flipped and shuffled several times.

After the shuffling stops, select the pair of 2 cards.

Repeat correctly 4 times to get a perfect score!

Market

If you select the first icon on the bottom row, you will go to the market. Here, you can buy ingredients required to make beverages.

After selecting the item you wish to purchase, it will show you the price.

your money

In this example, we are purchasing some jelly.

buy

don't buy

You have successfully purchased the item!

Blender

If you select the second icon on the bottom row (blender icon), you will be able to make beverages!

Step 1:

select a Tapi-Chan



Step 2:

Take note of Tapi-Chan's ingredient pairing request. In this example, it wants some jelly api-Chan

Step 3:

Select the jelly from your list of purchased ingredients.

Some beverages may require more than 1 type of ingredient, so you can select more than 1 ingredient from the list of all the ingredients you own.

If you don't have it in your inventory, go to the market and buy some more!



confirm

This area shows all the ingredients you have selected

Sometimes, the Tapi-Chan may request for ingredients that are not yet available for sale at the market. In this case, you will not be able to make that beverage until the ingredient is unlocked!

After you have confirmed all the ingredients you want to add into your beverage, select the "confirm" button.

Step 4:

After putting all the ingredients into the blender, move the straw left and right to mix the ingredients.

Continue mixing until it is done!

Different Tapi-Chans will have different pairing requests, so try all sorts of combinations to unlock new beverages!

Step 5:

Voila! You have made a beverage!

Collection Library

If you select the third icon on the bottom row (book icon), you will be able to see the list of all the Tapi-Chans, Beverages, and Ingrdients that you have unlocked.

view Tapi-Chans

view beverages and their ranks

view ingreadients

Rank 1-4

Rank 5 (special)

When you finish collecting all the different types of drinks in a rank, you will unlock one new game and one new beverage color.

With the new beverage color, you can now hunt and unlock more Tapi-Chans by creating new beverage combinations with the new color!

Settings

If you select the fouth icon on the bottom row (gear icon), you will be able to see settings.

This is where you can set the: volume, brightness, date, time, birthday, and also wipe all data.

Volume brightness date



time birthday wipe all data

If you select the Wipe Data icon, a message will pop up asking “are you sure?”

no

yes

If you select yes, the device will be reset and all progress will be erased.

Batteries

There will come a time that your batteries will run out.

Don’t worry all your data will be saved. Just replace them and you’re ready for collecting Tapi-Chans!

For more details
on how to play and advance
There is a seperate guide.

Happy hunting!

Photos: Rachel Liew
Instrucions: Rachel Liew
Graphic design: Celestial_Particle

@fuzzynchic_rachel
@koishigotchi

www fuzzy-n-chic.com